

## ATM WALL MOUNTING TEMPLATE





HOLE MARK ONE

220 mm

ATM DISPLAY





ATM QR CODE SCANNER/ CAMERA



ATM BILL ACCEPTOR



SCREWING TOOL





- 0. Make sure that template is printed correctly (distance between the holes should be 220mm).
- 1. Build the screwing tool based on the picture on the right.
- 2. Place this template on the wall into desired height.
- 3. Make sure the template is level.
- 4. Use a pencil to mark the position of the holes on the wall.
- 5. Remove the template and drill 2 marked holes with 10mm drill.
- 6. Insert the screw anchors (10mm) into the holes in wall.
- 7. Insert the screws (6mm) into the anchors.
- 8. Hang the ATM onto the wall on new screws.
- 9. Use a pencil to make mark the third bottom hole from within the ATM.
- 10. Remove the ATM and drill the third hole.
- 11. Insert screw anchor into the third hole.

12. Hang the ATM on the wall again.

- 13. Tighten the top screws.
- 14. Insert and tighten third bottom screw from within the ATM.



http://youtu.be/CU8avKGofiA

http://www.generalbytes.com/support

